C/S Tetras[™] Clean-off Carpet Tiles Installation Instructions

Floor Preparation

The sub floor should be level, clean, dry and should be free from grease dirt and other contaminants that will effect adhesion. If the floor is uneven a self-levelling latex skim should be applied. Any under floor heating must be switched off for 48 hours before and after installation. If the floor is dusty or absorbent it should be primed in accordance with the adhesive manufacturer's instructions.

Installation

(UK) Ltd.

Tiles can be loose laid or installed with double sided carpet tape or tackifier adhesive.

Loose Laid Tiles

Place the first tile in the centre of the matwell/mat area and build outwards to ensure that the mat is symmetrical. If required, cut tiles into shape using a Stanley knife.

Double Sided Tape or Adhesive.

An adhesive such as F.Ball F45 (or equivalent) should be used to adhere the Tetras Tiles performance textile to the sub floor (if a release bond is required then F45 should be used in conjunction with F.Ball F2 release sealer). Using a trowel spread the adhesive evenly over an area that can be covered within the open time of the adhesive, allow the adhesive to dry to a paste like consistency. Tetras Tiles should be conditioned at room temperature before installation.

Place the first tile in the centre of the matwell/mat area and build outwards to ensure that the mat is symmetrical. If required, cut tiles into shape using a Stanley knife.

Avoid walking on the tiles until a full bond is achieved, normally 24 hours.

All aspects of the installation should be in accordance with the requirements of BS5325:2001

Colour Options



SmokeyQuartz Z3711

his drawing/specification is the property of Construction Specialties (UK) Ltd and may not be reproduced in full or part or disclosed to any third



Moonstone Z3710



Obsidian Z3709



Sapphire Z3712

C/S Pedisystems®

Entrance Matting Systems v_{1.0}

Installation Instructions

All dimensions in millimetres unless otherwise stated. Do not scale from the drawing. If in doubt ask



Construction Specialties™



Construction Specialties (UK) Ltd 1010 Westcott Venture Park Westcott, Aylesbury Buckinghamshire HP18 0XB England

e-mail: info@c-sgroup.co.uk Internet: www.c-sgroup.co.uk

Fax: +44 (0)1296 652888